



## Clip In Climbing Hold Instructions

# CLIP IN

AC Adaptor plug in

ON/OFF switch

Top View



Bottom View

1. Plug in AC adaptor and charge internal battery for a minimum of 8 hours after receipt.
2. Make sure plug is fully inserted. If the hold flashes dimly with adaptor plugged in, then it is not fully plugged in.
3. Charge should last for several weeks. When LED's become dim, plug AC adaptor in for an additional 8 hours.
4. To turn the unit ON or OFF, simply use a small tool and press and release the ON/OFF switch.

### Adapter Specifications

O.D. = 5mm

I.D. = 2.1mm

Input - 120 VAC

Output Voltage - 7VDC

Output Current - 250 mA's



NOTE: Turning OFF unit between uses will prolong life between charges.